

1. Place the fixture in the framed alcove and ensure that the floor is level and the walls are plumb. The floor must be leveled prior to installation if it is more than 1/8" out-of-level
2. Turn the fixture over so that the support plate faces upward
3. Apply construction adhesive along the front threshold and along each rung of the support plate
4. Return the fixture to the upright position aligning the fixture drain with the waste pipe location
5. With the fixture in the upright position, carefully place at least 120 lbs of weight in/on the fixture until the adhesive cures. It's recommended to place the weights on top of something soft like a towel or cardboard to protect the gelcoat finish
6. To secure the fixture to the stud walls, pre-drill holes in each vertical stud surrounding the fixture. Pre-drill another hole at the base of the vertical flange. Nail or screw the fixture to the wall at each hole

Cleaning: It is recommended that general cleaning be performed using EverFab BathBrite cleaning solution. Avoid abrasive cleaning products as they may remove the glossy finish and make subsequent cleaning difficult